


Mobility Sound

全笙科技有限公司


BTD-XXX

Bluetooth Dongle for Radio
User Manual

1. Introduction of the product



2. Pairing with your Bluetooth headset



1. Press the PTT button down and hold it.
2. Switch the radio power from OFF to ON
3. Waiting for 3 seconds the LED will begin twice flash per second.
4. Release PTT and waiting for pairing.

3. Pairing with your BT-PTT (option)

1. Press the PTT button down and hold it.
2. Switch the radio power from OFF to ON
3. Waiting for 3 seconds the LED will begin twice flash per second. Then press PTT again the LED will be 3 flashes/sec. It's BT-PTT pairing mode.
4. Waiting for BT-PTT pairing.

4. Using

1. After pair the BTD-XXX with your Bluetooth headset then you can use the headset to hear and press the PTT button to talk.
2. If you paired with BT-PTT too then you can use both PTT to talk.

MobilitySound Technology LTD.

www.mobilitysound.com

info@mobilitysound.com

FCC:XTS-BTD-1M3

CE:W6M21009-10911-E-16

NCC:CCA111LP0600T1